

ANKER Euro Cash Cassette

More space for notes and receipts



The design of the Euro Cash Cassette follows the same principle as the Standard Cash Cassette. However, the size and the coin and note compartments are arranged differently. It is equipped with eight coin compartments and six note compartments. There is an additional compartment for receipts, which can be accessed from the outside using the drop-in slit. This configuration can accommodate any currency

Lockable cash cassette offers high security

The Euro Cash Cassette is electronically opened by the POS system. The cassette is equipped with a high-quality lock that can also be opened manually using a key. The lock is shipped with 50 different lock combinations. An optional plug lock is offered for additional security. The opening status of the Euro Cash Cassette is determined and transferred to the POS system via a switch built into the base.

Key benefits of the Euro Cash Cassette:

- Can be snap locked quickly easy removal by pressing the release button
- Long service life thanks to solid design and robust, durable plastic
- High-quality lock with up to 50 combinations, with safety lock available as an optional expansion
- Receipt compartment accessible from the outside for easy insertion of receipts



Suitable for all currencies. Secure storage without the need to open the cash drawer

Coin, note and receipt compartments

The cassette is equipped with eight coin compartments, six note compartments, a safe note compartment and a compartment for receipts. The receipt slot at the front of the Euro Cash Cassette allows cashiers to insert receipts for secure storage without having to open the Euro Cash Cassette.

Robust plastic cassette

The Euro Cash Cassette is made of robust and durable plastic. It is built for maximum longevity. In addition, the plastic used is environmentally friendly and easy to recycle.

Firmly mounted base plate

The Euro Cash Cassette system comprises a base and the Euro Cash Cassette. The base is firmly mounted to the POS counter and the Euro Cash Cassette can then be locked

onto the base. The base contains an electronic release unit. The cashier can simply open the cash cassette and press the release button to remove the cassette. This will unlock the cassette, which can then be removed with ease

Compatible with all commonly used POS systems

The Euro Cash Cassette can be used with all major POS systems. When the system is changed, all that needs to be replaced is the base

Optional accessories

- Additional security lock (2000 different lockings)
- External note holder
- Coin counting tray



Specifications

Components		Description
Measurements		482 mm x 100 mm x 175 mm
Weight	Cassette	Ca. 1,9 kg
	Base	Ca. 0,5 kg
Colours		Light grey RAL 9002
		Dark Grey RAL 7021
Electronic variations		12V, 24V, 36V, customized models
Base connection		5 pin DIN socket

For detailed information about our solutions, please contact us at:
info@aks-anker.de

ANKER hardware

User-friendly, versatile, flexible to use. Cash cassettes, cash drawers and Flexi-Stands from ANKER have proven themselves over and over again and offer an unparalleled functionality at point of service

Anker Kassensysteme GmbH

Werkering 6
 33609 Bielefeld

Tel.: +49 (0) 521 301 - 0
 Fax: +49 (0) 521 301 - 335

E-Mail: order.entry@aks-anker.de

www.aks-anker.de